


PARTS LIST


MODEL JS1004



PARTS LIST


PARTS LIST

Key No.	Item No.	Description
1	739601005	Rear cover (unit)
2	739002302	Rear cover
4	652205006	Spool pin
5	736007009	Spool pin spring
6	000076317	Tapping screw 3x10
7	735013005	Spool pin spring base
8	730006000	Spring
9	000101404	Set screw 4x6
10	000061205	Nut
11	739004005	Bed cover plate
12	000115205	Nut
13	000081005	Set screw 4x8
14	000121905	Tapping screw 4x12B
16	739607808	Front cover (unit)
17	739033612	Front cover
18	730501011	Thread guide plate (unit)
19	000160102	Adjustable lock nut 4
20	735016307	Bobbin winder stopper
21	000103107	Set screw 4x14
23	735040001	Thread guide
24	000107307	Tapping screw 3x8B
25	739079001	Extension table
26	739603309	Face plate (unit)
27	739011005	Face plate
28	366076000	Reflex sticker
30	739005006	Base plate
31	735616200	Rubber base (unit)
32	735002001	Rubber base
33	000097901	Flat screw 5x18
35	000061319	Nut




PARTS LIST

Key No.	Item No.	Description
1	735604009	Presser bar base plate (unit)
2	735023008	Presser bar base plate
3	735024009	Needle drop adjusting plate
4	000101404	Set screw 4x6
5	735025000	Needle bar supporter stopper
6	000070506	Plain washer
7	000116103	Wave washer 4
8	000138307	Bolt 4x8
9	735026001	Presser bar
10	735027002	Presser bar spring
11	735028003	Presser bar bracket
12	000111500	Hexagon socket screw 4x8
13	735029004	Presser foot lifter
14	000001609	Snap ring E-5
15	735030008	Tension release lever
16	000013903	Snap ring CS-5
17	000081005	Set screw 4x8
19	735503018	Presser foot
20	647112009	Thumb screw
21	739605002	Tension release arm (unit)
22	739017001	Tension release arm base
23	739018002	Tension release arm
24	739019003	Tension release spring
25	000002105	Snap ring E-3
26	739016000	Top cover thread guide
27	739604104	Tension assembly
28	735506217	Tension dial (unit)
29	000103808	Set screw 3x5
30	735040001	Thread guide
31	735041002	Check spring
32	652039007	Washer
33	000107307	Tapping screw 3x8B
34	000101703	Set screw 4x12
35	000002507	Snap ring E-4
36	735604009	Presser bar plate (unit)





PARTS LIST

Key No.	Item No.	Description
1	739068007	Face plate base plate
2	000081005	Set screw 4x8
3	730024004	Needle bar supporter spring
4	000101404	Set screw 4x6
5	654515008	Lamp socket (240V)
6	000009102	Lamp 240V
7	000053008	Cord tie band
8	735605103	Needle bar supporter (unit)
9	735032000	Needle bar supporter
10	730022002	Needle bar supporter pin
11	673022002	Spring washer
12	000070609	Plain washer
13	000002507	Snap ring E-4
14	000111304	Hexagon socket screw 5x5
15	670258000	Plain washer
16	678044005	Plain washer
17	735119002	Zigzag rod
18	678084007	Eccentric pin
19	730503116	Needle bar (unit)
20	553085019	Needle bar
21	801506008	Needle clamp (unit)
22	730025005	Needle guide plate
23	732105006	Needle clamp plate
24	802108009	Hinge screw
25	680043012	Needle bar thread guide
26	670047004	Flat head screw
27	102408089	Needle HA1-14
28	680504005	Needle bar connecting stud (unit)
29	670052002	Needle bar connecting stud
30	670272000	Needle bar connecting stud pin
31	000111201	Hexagon socket screw 4x4
32	680032007	Needle bar crank rod
33	735504008	Needle bar crank pin (unit)
34	735174005	Needle bar crank pin
35	647139002	Needle bar crank cap
36	625506109	Thread take-up lever (unit)
37	731511006	Thread take-up lever pin (unit)
38	647040005	Thread take-up lever pin
39	000002806	Snap ring E-6




PARTS LIST

Key No.	Item No.	Description
1	743603003	Upper shaft (unit)
2	743007001	Upper shaft
3	743008002	Take-up lever crank
4	000021708	Knock pin
5	102073003	Set screw
6	761052007	Set screw
7	000036717	Thrust washer FT-102
8	732025001	Upper shaft front bushing
9	639095000	Ring
10	000111304	Hexagon socket screw 5x5
11	751146008	Warm
12	553245008	Hexagon socket screw 4x4
13	000003601	Spring pin
14	743604004	Crank rod (unit)
15	743010007	Feed cam
16	743011008	Crank rod
17	639033000	Crank cam
18	639102012	Crank cam plate
19	000121400	Tapping screw 3x14B
20	743910006	Arm
21	000172602	Set screw 5x8
22	731312005	Felt
23	000030205	Snap ring E-8
24	743019006	Belt wheel
25	000023803	Spring pin
26	743029009	Felt
27	743606006	Handle wheel (unit)
28	639097024	Handle wheel
29	743030003	Balance weight
30	000121400	Tapping screw 3x14B
31	000014306	Snap ring CS-3
32	639113016	Clutch spring
33	000071013	Washer
34	810220003	Set screw
35	650070509	Clutch cap




PARTS LIST

Key No.	Item No.	Description
1	740615009	Zigzag mechanism (unit)
2	000081005	Set screw 4x8
3	740017005	Selector dial
4	743020206	Pattern indicating plate




PARTS LIST

Key No.	Item No.	Description
1	735017308	Handle
2	730015002	Handle shaft
5	000081005	Set screw 4x8
7	740003101	Bobbin winder base plate
8	735501005	Bobbin winder arm (unit)
9	735014006	Bobbin winder arm
10	735129005	Bobbin winder shaft
11	670026007	Bobbin winder shaft spring
12	652092008	Bobbin winder shaft ring
13	647017003	Bobbin winder ring base
14	647018004	Bobbin winder ring
15	735015007	Bobbin winder arm spring
16	000002806	Snap ring E-6
17	736607016	Feed regulator (unit)
18	647049004	Feed regulator
19	736028006	Feed regulator plate
20	601024001	Pin
21	735077007	Feed regulator spring
22	735073003	Plain washer
23	000013800	Snap ring CS-6
24	648010009	Set screw
25	000160102	Adjustable lock nut 4
26	648012001	Set screw
27	740096008	Feed regulator rod
28	000002105	Snap ring E-3
29	730045001	Reverse link
34	000172602	Set screw 5x8
35	739066005	R button
36	739063002	R button spring
37	736015000	R button shaft
38	000001609	Snap ring E-5
39	000014007	Snap ring CS-4
40	670100006	Feed regulator spring








PARTS LIST

Key No.	Item No.	Description
1	735612000	Feed rock shaft (unit)
2	735078008	Feed rock shaft
3	735079009	Feed bar
4	735080003	Feed bar shaft
5	000002507	Snap ring E-4
6	000111201	Hexagon socket screw
7	735081004	Feed dog
8	735082005	Set screw
9	735083006	Feed bar spring
10	735084007	Feed rock shaft center
11	735085008	Feed rock shaft center plate
12	000101404	Set screw 4x6
13	735613001	Feed lifting arm (unit)
14	735086009	Feed lifting arm
15	605030002	Sliding plate
16	365032001	Set screw
17	735087000	Feed lifting pin
18	735088001	Feed lifting roller
19	735089002	Feed lifting spring
20	735090006	Feed lifting shaft
21	000097200	Set screw 4x12
22	739022009	Feed lifting shaft holder
23	000081119	Set screw 4x6
24	743012009	Feed rod
25	743013000	Feed rod spring
26	102141003	Feed regulator slide block
27	735071001	Feed rock shaft connecting pin
28	000002806	Snap ring E-6
29	735276008	Ring



PARTS LIST

Key No.	Item No.	Description
1	744004001	Needle plate
2	681009101	Set screw
3	735950003	Lower shaft gear (unit)
4	735951004	Lower shaft gear
5	000110107	Hexagon socket screw 5x5WP
6	000036201	Washer 8-0.5
7	735233003	Bushing
8	735061008	Feed lifting cam
9	000111304	Hexagon socket screw 5x5
10	735236006	Lower shaft
11	735239009	Felt holder
12	822070003	Felt
13	735234004	Bushing
14	639036003	Lower shaft crank arm
15	639037004	Pin
16	000001609	Snap ring E-5
17	735610101	Shuttle body (unit)
18	735508105	Shuttle race body (unit)
19	735065002	Shuttle race body
20	605065006	Shuttle race ring clasp (right)
21	605066007	Shuttle race ring clasp (left)
22	639108007	Shuttle race ring clasp spring
23	673290003	Hinge screw
24	553168006	Shuttle race ring
25	601801000	Shuttle race spring
26	102100000	Set screw
27	735509003	Driver body (unit)
28	735066003	Driver body
29	670286007	Shuttle driver spring
30	102202003	Plain screw
31	735067004	Ring
32	553245008	Hexagon socket screw
33	735068108	Shuttle race body shaft gear
34	532096007	Shuttle hook
35	647515006	Bobbin case (unit)
36	102261000	Bobbin



PARTS LIST

Key No.	Item No.	Description
1	739503102	Machine socket (unit)
2	739036006	Machine socket
3	000060802	Nut
4	655513009	Switch for 240V
5	739037007	Machine socket cover
6	000107802	Set screw 3x10
7	000103509	Set screw 4x10
8	739035201	Belt cover
9	000115205	TP screw 4x6
10	650166008	Timing belt
11	000201209	TP screw 5x12
12	743611107	Motor (unit)
13	042870306	Foot controller (unit)

