




Parts List



AstraLux 
art of sewing
Model 9710

A-1





No.	Part No.	Description
1	Y4A0403210	Back cover
2	V610155000	Thread guide complete
3	004230326	Set screw (M3×12)
4	E1A2065000	Bobbin winder thread guide complete
5	E1A2053001*	Bobbin winder thread guide adjusting screw
6	H13153001*	Bobbin winder thread guide spring
7	H13133001*	Bobbin winder spring disc
8	V610223001*	Bobbin winder thread guide
9	E1A2353006*	Spacer
10	003010036	E-Ring (ETW-3)
11	004840106	Nut (ALN-4)
12	E1A2043001	Thread guide
13	004230216	Set screw (M3×8.5)
14	D2BA003210	Arm top cover
15	004240106	Set screw (M4×8 A)
16	E1A1663210	Spool rod
17	004230656	Set screw (M3×1.06)
18	008870000	Row line
19	E1A1763210	Handle
20	004706013	Nut (9/64×40 t=3)
21	E1A2393000	Bobbin winder stopper
22	E1A1673002	Arm back cover set plate
23	D2BD004210	Dial tension complete
24	Y1A0183210	Dial tension supporter plate cover
25	E1A2283000	Thread guide spring
26	004300976*	Washer(3.2×10.5×0.5)
27	Y4A0253003	Dial tension set spring
28	E1A214300	Thread guide pin
29	E1A2193000	Thread spring stopper
30	E1A2163000	Thread guide roller supporter
31	E1A2153000	Thread guide roller
32	E1A2133000	Thread guide roller pin
33	Y4A0193002	Dial tension supporter plate
34	008D2B0007	LCD
35	YTA0383003	Dial tension waft plate

No.	Part No.	Description
36	003010046*	E-Ring (ETW-4)
37	Y4A0573001	Dial tension disc (left)
38	H10133211	Sewing table body guide
39	V10443000	Dial tension spring regulator
40	NB1083000	Dial tension spring
41	003041612	Shank complete spring pin
42	Y4A0583001	Dial tension disc (right)
43	D2BD003210	Dial tension knob
44	004230016*	Set screw (M3×6 A)
45	Y4A0243000	Dial tension regulate nut
46	Y4A0563003	Dial tension set plate
47	004230666	Set screw (M3×6)
48	004240046	Set screw (M4×10 B)
49	Y4A0233001	Dial tension disk plate
50	Y4A0223002	Dial tension crank
51	004241106*	Set screw (M4×25)
52	004240146*	Set screw (M4×15 B)
53	004240982	Set screw (M4)
54	Y4A0593001	Dial tension guide spring tube
55	YTA0104000	Bobbin winder frame complete
56	YTA0113002	Bobbin winder frame
57	008667000	Micro switch complete
58	004220112	Set screw (M2×7.5)
59	D2B0123000	LCD plastic cover
60	D3A0653002	Front cover set plate(2)
61	D2BN043210	Adjust button(—)
62	D2BN053210	Adjust button(—)
63	V61503210	Plate (1)
64	D3A0505000	Bobbin winder crank complete
65	F20213000	Bobbin winder rubber pulley
66	F20193000	Bobbin winder crank spring
67	003011052	E-Ring (ETW-5)
68	H10143003	Sewing table body guide spring
69	004240056	Set screw (M4×6 B)
70	D2BF003210	Face plate


No.	Part No.	Description
71	004241061	Set screw (M4×12 B)
72	Y4A0213003	Dial tension spring
73	003020053*	Cs ring (CSTW-5)
74	V630593000	Thread cutter
75	008891009	Slide volume complete
76	004106162	Set screw (9/64×40×16)
77	E1A2523000	Heat resistant plate
78	D2BC003210	Front cover (For electronic)
79	E9R0803210	Plug
80	D2B0073763	Start/stop push knob
81	008884009	Up & down fixed position switch
82	E1A1623002	Arm front cover set plate
83	YMA0163210	Slide volume knob connector
84	YMA0153210	Slide volume knob (for Electronic)
85	D2BN063210	Adjust button(二)
86	D2BN073210	Adjust button(二)
87	D3A0713002	Arm top cover plate(1)
88	D3A0723002	Arm top cover plate(2)
89	E4G6013210	Free arm base
90	004240136	Set screw (M4×12 B)
91	Y4A0473210	Free arm foot bush
92	Y1A0283002	Arm top cover thread guide plate
93	004230746	Set screw (M3×12)
94	E1A1843000	Sewing table body felt
95	Y4A0484210	Sewing table complete
96	Y4A0483210	Sewing table body
97	Y4A0493210	Sewing table body cover
98	YTA0723210	Cord reel cover
99	004300202	Washer (4.5×10×0.8)
100	D3B4083000	LED plastic cover
101	Y4A0603002	Front cover set plate(right)
102	YTA0423210	Motor drive belt cover (For electronic)
103	E1A1723003	Motor drive belt cover frame
104	004241106	Set screw (M4×0.7 L = 25)
105	D2B0093210	Key cover

***means: These spare parts are not supplied individually, but can be obtained by minimum quantity at 300 pcs.

No.	Part No.	Description
106	D2BN003210	Needle position knob
107	D2BN233210	Needle repair knob
108	D2BN243210	Needle return knob
109	D2BN083210	Function set knob(left)
110	D2BN093210	Function set knob(center)
111	D2BN103210	Function set knob(right)
112	D2BN113763	Numeral knob(M)
113	D2BN123763	Numeral knob(7)
114	D2BN133763	Numeral knob(4)
115	D2BN143763	Numeral knob(1)
116	D2BN153763	Numeral knob(0)
117	D2BN163763	Numeral knob(8)
118	D2BN173763	Numeral knob(5)
119	D2BN183763	Numeral knob(2)
120	D2BN193763	Numeral knob(C)
121	D2BN203763	Numeral knob(9)
122	D2BN213763	Numeral knob(6)
123	D2BN223763	Numeral knob(3)

***means: These spare parts are not supplied individually, but can be obtained by minimum quantity at 300 pcs.

B




No.	Part No.	Description
1	E1A2685000	Thread take up lever complete
2	Y1A0093000	Thread take up lever supporter
3	003010036*	E-Ring (ETW-3)
4	V10533003	Thread take up lever supporter shaft
5	H13093003	Set washer
6	004240106*	Set screw (M4×8 A)
7	E1A2663000*	Arm shaft balance pin
8	E1A2213000	Arm shaft balance
9	004240223	Set screw (M4×6 C)
10	003043524	Arm shaft balance pin (φ3.5×24)
11	003010093	E-Ring (ETW-9)
12	R10293000	Arm shaft bushing
13	E1A2623003	Arm shaft bushing holder plate
14	004400080	Endure attrition washer (10.2×15×0.5)
15	R10304000	Arm shaft collar complete
16	004250203	Set screw (M5×5 C)
17	D3A0033000	Rotary sensor collar
18	008410000	Revolution control panel
19	004840022	Nut (M4 t=3)
20	004240033	Set screw (M4×5 C)
21	E1A0083000	Motor drive belt
22	F4A0033000	Arm shaft sprocket
23	F80093003	Position rod
24	004300853*	Washer (10.2×15×0.5)
25	E4A0143210	Arm shaft drive belt pulley
26	D3A0023000	Arm shaft
27	D3A0043002	Arc washer
28	003043018*	Spring pin (φ3×18)
29	R10393000	Arm shaft clutch annulus spring
30	R10403000	Arm shaft collar
31	E1A0073210	Hand wheel
32	004300586*	Hand wheel washer (5.2×16×1.0)
33	004250346*	Set screw (M5×10)
34	V16893210	Hand wheel decorated plate
35	007163471	Motor drive belt (163XXL6.1)

No.	Part No.	Description
36	Y1A0103003	Action link
37	003010043	E-Ring (ETW-4)

***means: These spare parts are not supplied individually, but can be obtained by minimum quantity at 300 pcs.

C




No.	Part No.	Description
1	Y1A0013000	Arm
2	YTA0093002	Zigzag pulse motor plate
3	008291000	Photo sensor complete (zigzag)
4	001D3B1001	Pulse motor
5	D3A0113000	Pulse motor gear
6	004230433	Set screw (M3×3)
7	D3A0123000	Zigzag crank (1)
8	D3A0133000	Zigzag crank (2)
9	D3A0143003	Crank spring
10	YTA0203000	Micro switch seat(2)
11	003020023	Cs ring (cstw-2)
12	008693000	Micro switch complete
13	D3A0163002	Needle bar driving rod plate
14	004300916	Washer (5×12×0.5)
15	003010046	E-Ring (ETW-4)
16	YTA0133006	Photo sensor support plate
17	008694000	Photo sensor check complete
18	004230702	Set screw (M3×5A)
19	004240033	Set screw (M4×5 C)
20	004240863	Needle bar supporter screw
21	004260023	Set screw (M6×5 C)
22	Y1A0544000	Slide cutting
23	YTA0244000	Needle plate complete
24	004230702	Set screw (M3×5 A)
25	Z11993211	Presser bar regulating screw
26	E1A0143002	Presser bar
27	V11543003	Presser bar spring
28	H10533002	Presser bar bracket
29	Y4A0063003	Tension lever lifter
30	003010053	E-ring (E-5)
31	Y4A0685000	Needle bar supporter pin collar complete
32	Y4A0073000	Presser bar lifter lever
33	006187008	Shank complete
34	004106221	Shank complete set screw
35	006186008	Zip zap presser foot complete
36	H10723003	Tension lever lifter spring

No.	Part No.	Description
37	YTA0213004	Needle plate
38	NB1293000	Needle plate cover
39	004240851	Set screw (M4×6)
40	NB0233000	Needle plate cover open
41	E1A2593000	Needle plate cover
42	004103072	Set screw (SM3/32×56 L=3)
43	E1A0584000	Rotary hook plate complete
44	E1A0593002	Rotary hook plate (1)
45	004240056	Set screw (M4×6 B)
46	Y4A0043000	Needle bar supporter
47	NB0533000	Needle bar
48	003080052	Ring (BETW-5)
49	E1A1893000	Needle bar supporter pin
50	YTA0204000	Micro switch seat complete
51	V61243003*	Clutch rod spring
52	YTA0173003	Needle bar driving rod
53	E1A2433000	Needle bar driving rod pin
54	E1A0113000	Auto threaded shaft
55	R12793003	Auto threaded shaft spring
56	003042014	Auto threaded shaft pin
57	004230433	Set screw (M3×3 C)
58	004106202	Set screw (M4)
59	E1A0123000	Auto threaded lever
60	M70093000	Auto threaded lever spring
61	E1A2125000	Auto threaded
62	H10525000	Presser bar bracket complete
63	V60143003	Tension regulating plate
64	H10205000	Needle clamp complete
65	R12573000	Needle guide plate
66	Y1A0613000	Needle bar thread guide
67	004103011	Set screw (3/32×56×4.1)
68	006046148	Needle
69	M70073002	Auto threaded stopper
70	004230016	Set screw (M3×6 A)
71	H10195000	Needle bar crank rod complete
72	V60163000	Presser bar lifter lever screw cushion

No.	Part No.	Description
73	YTA0124000	Photo sensor support plate complete
74	004240046	Set screw (M4×10B)
75	004240503	Set screw (M4×4 C)
76	003042006	Spring pin (Ø2×6 t=4)
77	*004240106	Set screw (M4×8 A)
78	YTA0523003	Needle bar driving rod spring plate
79	V61205003	Clutch rod complete
80	V61213003*	Clutch rod plate
81	V61233003*	Clutch rod
82	E1A2603000	Needle plate spring
83	004103081	Set screw (SM3/32×56 L=5)
84	H10253000	Needle plate bracket (1)
85	H10263000	Needle plate bracket (2)
86	F4A3343000	Needle bar crank rod
87	004230702	Set screw (M3×5 A)
88	E1A2913000	Needle plate cover plate
89	E1A2343003	Spring
90	D3A0523002	Arm top cover plate
91	004240066	Set screw (M4×8 B)
92	YTA0233003	Set screw
93	003010043	E-ring (E-4)
94	Y4A0683003	Needle bar supporter pin collar
95	E1A0603002	Rotary hook plate (2)
96	F30893000	Rotary hook plate spring (2)
97	F30883000	Rotary hook plate spring (1)
98	004220056	Set screw (M2×2.5)
99	Y1A0624000	Combine rod complete
100	Y1A0623003	Combine rod (1)
101	Y1A0633003	Combine rod (2)
102	Y1A0643000	Combine rod cover
103	004300676	Washer (3.2×8×0.7)
104	004230286	Set screw (M3×8 B)
105	E1A2923000	Needle plate cover spring
106	004225106	Set screw (M2.5×3)

*** means: These spare parts are not supplied individually, but can be obtained by minimum quantity at 300 pcs.

D




No.	Part No.	Description
1	YTA0053003	BH lever plate
2	D3A0473000	BH lever crank spring
3	D3A0453000	BH movement crank
4	005012011	Lamp (12V 5W)
5	YTA0183003	BH lever crank
6	YTA0063006	BH Board set screw
7	D3A0933003	Belt adjusting plate
8	D3A0935000	Belt adjusting plate complete
9	H12323000	Belt adjusting plate pulley
10	E1A1493002	BH lever
11	E4A6003210	BH lever button
12	D3A0563000	Motor cushion
13	D3A0573000	Motor fixed bushing
14	004230902	Set screw (M3×4)
15	003010043	E-Ring (ETW-4)
16	008598210	Receptacle holder
17	008604000	Controller receptacle
18	004230513	Set screw (M3×3 C)
19	D3A0543000	Motor wheel
20	004240106 *	Set screw (M4×8 A)
21	004240046	Set screw (M4×10 B)
22	008669000	Trance former(PT-2841)230V
23	001496409	Foot controller (C-9000)
24	YTA0073002	Lamp fixed board
25	004230702	Set screw (M3×5 A)
26	008D2B0005	Main circuit board
27	001040309	MG Motor complete (RS775SH) 12V
28	004300306	washer (5.4×10×0.9)
29	D3A0533006	Motor bracket
30	002531708	Switch receptacle ass'y (230V~240V)
31	D3A0603000	Trance former cover (1)
32	D3A0613000	Trance former cover (2)
33	004241156 *	Set screw (M4×50)
34	004240146 *	Set screw (M4×15 B)
35	008666000	Mg motor leading wire complete

No.	Part No.	Description
36	004250086 *	Set screw (M5×12)
37	004600296	Spring washer (5.1×9.2×1.3)
38	004240136	Set screw (M4×12 B)
39	004220152	Set screw ((M2×10 B)
40	YTA0374000	Lamp receptacle complete
41	002027129	Cord clip
42	002030129	Cord clip
43	008703000	Photo sensor complete
44	003041605	Spring pin
45	001040308	MG Motor complete
46	YTA0443003	Photo sensor plank
47	D3A0923000	Insulating sleeve
48	008692000	Micro switch(B/H)
49	YTA0163000	Micro switch set
50	E1A1483003	BH lever spring plate
51	004240676	Set screw (M4×5 B)
52	008D3B0013	Safety wire complete
53	004230016	Set screw (M3×6)
54	YTA0045000	BH lever plate complete
55	004230076	Set screw (M3×5 A)
56	002542118	Supply cord (230V)

***means: These spare parts are not supplied individually, but can be obtained by minimum quantity at 300 pcs.

E




No.	Part No.	Description
1	NB0693000	Bobbin shaft oil cloth
2	E1A2033000	Bobbin shaft
3	NB0673000	Bobbin shaft washer (2)
4	004400840	Endure attrition washer (6.2×9.6×0.5)
5	NB1275000	Shuttle hook complete
6	NB0643000	Magnet
7	NB1265000	Shuttle hook holder complete
8	NB0683000	Bobbin shaft washer (3)
9	E1A0563000	Shuttle hook cover
10	004230066	Set screw (M3×12)
11	D3A1653000	Feed crank shaft
12	E1A0523000	Rotary hook holder
13	E1A0553000	Rotary hook holder positioned plate
14	004240056	Set screw (M4×6 B)
15	E1A0543000	Rotary hook supporter
16	004240033	Set screw (M4×5 C)
17	004240106	Set screw (M4×8 A)
18	K82133006	Base plate adjustment screw
19	H70043000	Free arm vase cushion rubber
20	004241202	Feed regulating crank set screw
21	E1A0573210	Feed lifting shaft
22	E1A0373000	Feed rock shaft
23	E1A0403003	Fed rock frame shaft (2)
24	004240503	Set screw (M4×4 C)
25	E1A0423003	Feed rock frame shaft (1)
26	D3A0793003	Feed rock bushing pin
27	003010043	E-Ring (ETW-4)
28	NB0495000	Lower shaft gear complete
29	D3A0353003	Feed shaft spring
30	D3A0343000	Feed rock crank
31	F30323003	Feed rock crank pin
32	004240223	Set screw (M4×6 C)
33	003010036	E-Ring (ETW-3)
34	F30284000	Feed cock shaft collar complete
35	E1A0413000	Feed rock frame

No.	Part No.	Description
36	YTA0223001	Feed dog
37	004104012	Set screw (1/8×44×5)
38	E1A0443003	Feed rock crank pin (1)
39	E4A0223002	Feed rock crank
40	E1A0453003	Feed lifting rock crank
41	004840106	Adjusting nut
42	004240633	Feed back crank screw
43	E1A0345000	Belt adjusting plate complete
44	E1A0353000	Belt adjusting plate
45	H12323000	Belt adjusting plate pulley
46	V11564000	Lower shaft collar complete
47	F30333000	Feed regulating block
48	D3A0254000	Feed regulating plate complete
49	F30353000	Feed regulating
50	004400570	Endure attrition washer(6.7×11.8×0.5)
51	R11443000	Feed rock bushing
52	004300123	Washer (6.7×12×1)
53	003010053	E-Ring (ETW-5)
54	D3A0253000	Feed regulating shaft
55	D3A0263003	Feed crank (1)
56	D3A0943000	Feed rock rod
57	004240586	Set screw (M4×8)
58	D3A0273003	Feed regulating crank
59	E1A0283000	Lower shaft bushing
60	NB0503000	Lower shaft gear
61	003010063	E-Ring (ETW-6)
62	E1A0305000	Feed lifting rock cam complete
63	E1A0290000	Feed lifting rock cam
64	E1A0333003	Lower shaft spring
65	004400830	Endure attrition washer (8.2×12×0.5)
66	E1A0325000	Feed rock cam complete
67	D3A0063000	Lower shaft
68	V11553003	Lower shaft collar
69	E1A2343003	Feed dog frame spring
70	E1A0313000	Lower shaft belt pulley


No.	Part No.	Description
71	004230673	Set screw (M3×14.5)
72	E1A2573006	Base plate adjustment screw spring
73	E1A2503000	Free arm vase cushion rubber
74	D3A0193006	Pulse support plate
75	008291000	Photo sensor complete
76	004230702	Set screw (M3×5 A)
77	001D3B1001	Pulse motor complete
78	D3A0113000	Pulse motor gear
79	004230433	Set screw (M3×3 C)
80	D3A0223000	Feed rock crank (1)
81	D3A0233000	Feed rock crank (2)
82	D3A0143003	Zigzag width feed rock crank spring
83	003010046	E-Ring (ETW-4)
84	D3A0293003	Feed regulating crank spring
85	004300136	Washer (4.2×8×0.8)
86	004230776	Set screw (M3×12)
87	H12883000	Steel ball
88	E1A1873003	Feed lifting shaft spring

*** means: These spare parts are not supplied individually, but can be obtained by minimum quantity at 300 pcs.

Standard accessories



Optional accessories



Standard accessories		
No.	Part No.	Description
1	006186008	All purpose foot (No. T)
2	006905008	Zipper foot (No. I)
3	D3B1524000	Buttonhole foot (No. I)
4	006813008	Cording foot(No. M)
5	006907008	Overcastting foot (No. E)
6	006904008	Blind hem foot (No. F)
7	006900008	Hemmer foot (No. K)
8	006172008	Satin stitch foot (No. A)
9	006916008	Quilting foot (No. P)
10	006166008	Slide cutting foot complete
11	006016008	Darning Embroidery foot
12	006917008	Gathering foot
13	006914008	Button sewing foot
14	006099008	Brush & Seam ripper complete
15	R12373210	Spool set plate (Big)
16	TA10943209	Spool holder (Small)
17	006008001	Seam guide
18	006084009	Bobbin
19	006012008	Screw drive
20	006014148	Needle
21	006015009	Second spool pin
22	R60033210	Second spool pin
23	006020008	Twin needle

Optional accessories		
No.	Part No.	Description
A	0061850081	Walking foot

NOTE: When you order any spare parts from us, please cooperate with us by writing.

(1) Section, Sequence No, and Parts NO.

(2) Name of parts

(3) Voltage, if necessary

(4) Others, if any

A210D2B57

AUG 08 22, '07

***means: These spare parts are not supplied individually, but can be obtained by minimum quantity at 300 pcs.